

The table shows all of the features of the sliding-gate operator dedicated control panels. Those in bold-type are important when selecting which operator to fit and should be considered from the start.

Models / Series	24		24							24
	BX-243 BX-243C	BX-74 BX-78	BX-P	BX-246	BX-10	BK-800 BK-1200 BK-1800 BK-2200	BKE-1200 BKE-1800 BKE-2200	BK-1200P	BK-221	BK-2200T BY-3500T
Control board / Control panel	ZN2	ZBX74 ZBX78	ZBX8	ZD2	ZBX10	ZBK	ZBKE	ZBK8	ZBK10	ZT6 ZT6C
Features	Safety									
SELF-DIAGNOSIS of safety devices	●			●	●	●	●	●	●	●
PRE-FLASHING during opening and closing	●	●	●	●	●	●	●	●	●	●
RE-OPENING during closing	●	●	●	●	●	●	●	●	●	●
RE-CLOSING during opening	●	●		●	●	●	●		●	●
Obstacle STALL					●				●	
TOTAL STOP	●	●	●	●	●	●	●	●	●	●
PARTIAL STOP	●	●	●	●	●	●	●	●	●	●
OBSTACLE DETECTION in front of photocells	●	●	●	●	●	●	●	●	●	●
ENCODER	●						●			
MOVEMENT CONTROL and OBSTACLE DETECTION device		●		●	●				●	
AMPEROMETRIC DETECTION	●			●						
Command										
PEDESTRIAN OPENING										
PARTIAL OPENING	●	●	●	●	●	●	●	●	●	●
ONLY-OPEN feature with transmitter and/or button	●	●	●	●	●	●	●	●	●	●
Button connection for ONLY-OPEN or ONLY-CLOSE feature**				**	●	●	●	●	●	●
OPEN-STOP-CLOSE-STOP from transmitter and/or button	●	●	●	●	●	●	●	●	●	●
OPEN-CLOSE-REVERSE from transmitter and/or button	●	●	●	●	●	●	●	●	●	●
MAINTAINED ACTION	●	●	●	●	●	●	●	●	●	●
DELAYED OPENING of 1st leaf										
DELAYED CLOSING of 2nd leaf										
IMMEDIATE CLOSING										
EMERGENCY RELEASE from transmitter			●					●		
Characteristics and adjustments										
Output for connecting the FLASHING LIGHT	●	●	●	●	●	●	●	●	●	●
Output for connecting the CYCLE LAMP		●	●		●	●	●		●	●
Output for connecting the COURTESY LAMP					●	●	●		●	●
Antenna	●	●	●	●	●	●	●	●	●	●
Output for connecting the SIGNALLING LAMP (gate open)	●	●	●	●	●	●	●	●	●	●
Output for connecting the SIGNALLING LAMP (gate closed)		●	●							●
Contact output for 2nd RADIO CHANNEL		●		●		●	●			●
OPERATION TIME adjustment					●				●	
SELF-LEARNING of transmitter RADIO CODE	●	●	●	●	●	●	●	●	●	●
Output for connecting ELECTRIC LOCK and/or "WATER HAMMER"										
Adjustable TIME before AUTOMATIC CLOSING	●	●	●	●	●	●	●	●	●	●
Slow-down during OPENING and/or CLOSING	●	●		●	●				●	
EMERGENCY FUNCTIONING with batteries (optional)	●			●						
MASTER-SLAVE						●	●			●
Adjustable SLOW-DOWN and FUNCTIONING speed*	●	●*		●	●*				●*	
DISPLAY					●				●	
Electronic BRAKE		●		●	●	●	●		●	●
Endstop SELF-LEARNING of open and close positions										
SLEEP MODE										
Output for connecting the SOLAR PANEL										

● 230 – 400 V AC THREE-PHASE ● 230 V AC ● 24 V DC INTENSIVE SERVICE

NOTES

* For 001BX-10 - 001BX-74 - 001BX-78 e 001BK-221 slow-down speed only.

** For 001BX-246 ONLY-OPEN function.